



Final/Production #19750-751
Quote # 5394

Prepared For:
SERVS
309 FM 3381
Comanche, TX 76442
Phone:
Fax:

Presented By: Bo Starnes
SERVS
309 FM 3381
Comanche, TX 76442
Phone: 800-561-6070
Fax:

Option	QTY	Description
Chassis		
1000-0002	1	AMBULANCE SPECIFICATIONS
1000-0688	1	CHASSIS, 2020 FORD F-550 4X4, 193 The chassis required to complete the ambulance conversion shall be supplied by Horton.
1000-0071	1	CHASSIS ORDERED WITH ALUMINUM WHEELS The specified chassis is to be ordered to include OEM aluminum wheels.
1000-0451	1	PASS THROUGH CAB/MODULE, F SERIES Install a pass-through opening between the cab and module. Pass-through to include a bellows connection.
1000-0067	1	DIESEL EXHAUST FLUID FILL, F SERIES Install a label next to the DEF fill stating that the fill is to be used for DEF only.
1000-0474	1	VALVE EXTENSIONS, ALUM WHEELS, F SERIES Install stainless steel braided filler extensions on the rear tires. Fasten to the center wheel hub with stainless steel brackets.
1000-0083	1	STANDARD CAB HEIGHT The specified chassis will have the standard cab height.
1000-0346	1	MUD FLAPS, REAR, LARGE W/LOGO Install individual rear mud flaps behind each set of rear wheels. Mud flaps to include Horton logo.
1000-0090	1	REINFORCE REAR BUMPER END CAPS Reinforce end caps of rear bumper for greater impact resistance.

1000-0223	1	RUNNING BOARDS: EMB.W/STAR PUNCH, F SERIES Install heavy duty aluminum embossed diamond plate running boards and splash shields. Running boards are to be star punched for enhanced drain and foot grip.
1000-0227	1	REAR STEP/ BUMPER ASSEMBLY, F SERIES Install a diamondplate rear step/bumper assembly with flip-up center section.
1000-0149	1	LIQUID SPRING SUSPENSION, F 550 Install a Liquid Spring hydraulic rear suspension. Wire system to dump when the left rear entry door is opened. Install manual controls in the cab near the driver.
1000-0152	1	FRONT STABILIZER BAR: FORD F-SERIES Remove the OEM front stabilizer bar and install Roadmaster brand aftermarket stabilizer bar.
3000-0407	1	RECEIVER/DRYER KIT, FORD F-SERIES CHASSIS Install standard receiver/dryer kit w/pressure switch in the air conditioning system.
BODY		
2000-0149	1	AMBULANCE BODY Conversion model is to be a 603F-I using a Ford F Series chassis. Body length is 167".
2000-0013	1	HEADROOM, 72" The headroom is to be 72".
2000-0625	1	ALUM. DIAMONDPLATE AT SIDE STEPWELL Fabricate the stepping surface inside the side access door using polished aluminum diamond treadplate.
2000-0245	1	DOUBLE STEP CURBSIDE ENTRY, 6" DROP SKIRT Fabricate curbside of body with 6" drop skirt. To include two step side entry.
2000-0247	1	NO BODY DROP, STREETSIDE The streetside body forward of the rear wheels will not have a drop skirt.
2000-0250	1	SOUND PROOFING/ACOUSTIC ENHANCEMENT PACKAGE Install standard sound control package.
2000-1050	1	ROOF POCKET, AUXILIARY CONDENSER Install a roof pocket for a CoolTech I unit.
2000-0259	1	PRIVACY WINDOWS, FIXED, REAR ENTRY DOORS Install privacy tinted solid fixed windows in the rear module access doors.
2000-0263	1	PRIVACY WINDOW, SLIDING FOR SIDE ENTRY DOOR Install a sliding tinted privacy window in the side access door.

2000-0265	2	EMERGENCY RELEASE, REAR DOORS Install standard emergency release knobs on top and bottom of the rear module entrance doors.
2000-0704	1	EMERGENCY RELEASE, SIDE ACCESS DOOR Install emergency release knobs on top and bottom of the side module entrance door.
2000-0010	1	DOOR HANDLES Install Tri-Mark free floating style door handles with pre-stretched stainless steel cables. Include three piece interior door panels on all access doors.
2000-0811	1	VI-TECH MOUNTING, F SERIES Install standard Vi-Tech body mounts.
2000-0270	1	MIRROR STAINLESS STEEL SPLASH SHIELDS Install #8 mirror stainless splash shields on the lower front face of the body just behind the cab access doors. These splash shields are to be the same height as the diamond plate front corner guards.
2000-0596	1	PRE PUNCH SPLASH SHIELDS The specified front splash shields are to be pre-punched to accept the specified running board lights.
2000-0510	1	FENDER, STAINLESS Install a stainless steel fender at the streetside rear wheelwell location. Fender for standard wheel opening with no drop skirt.
2000-0690	1	FENDERS, STAINLESS, STD, CS 6" DROP SKIRT Install a stainless steel fender, for use in conjunction with a 6" drop skirt, at the curbside rear wheelwell location.
2000-0273	1	POLISHED STAINLESS RUB RAILS Polished stainless lower body rub rails, with #8 mirror finish, are to be installed along the bottom of the body on each side fore and aft of the rear wheels.
2000-0652	1	STANDARD CORNER GUARDS Install standard height polished diamondplate corner guards.
2000-0281	1	REAR DOOR HOLD OPENS, GRABBER Install chrome Cast Products "Grabber" style rear door hold opens. (NOTE: HOLDOPENS MUST BE RELOCATED IF TELESCOPIC LIGHTS ARE ORDERED)
2000-0584	1	REAR RISER ADP The rear riser is to be fabricated out of polished aluminum diamondplate.
2000-1103	1	LICENSE PLATE, STREETSIDE REAR RISER Drill two mounting holes for the rear license plate on the streetside of the rear riser. Install an LED license plate light. include bolts with which the plate shall mount.
2000-0598	20	DOOR REFLECTORS All patient compartment entry doors to include standard red reflectors.
COMPARTMENTATION		
2900-1514	1	STREETSIDE FORWARD COMPARTMENT

		The height of the streetside front compartment is to be the full available height of the body. See drawings for compartment dimensions. Compartment is to include standard LED strip lighting and a single hinged door.
2000-0400	1	SS FORWARD COMPT. DIAMONDPLATE The streetside forward compartment is to be fabricated from diamondplate.
2900-1517	1	STREETSIDE INTERMEDIATE COMPARTMENT The height of the streetside intermediate compartment is to be the full available height to the bottom of the interior countertop. See drawings for compartment dimensions. Compartment is to include standard LED strip lighting and double hinged doors.
2000-0402	1	SS INTRMDT COMPT. DIAMONDPLATE The streetside intermediate compartment is to be fabricated from diamondplate.
2900-0144	1	ADJUSTABLE SHELF STREETSIDE INTERMEDIATE - Left side of divider Install diamond plate adjustable shelving in the streetside intermediate compartment. Locate as noted.
2900-0242	1	ELECTRICAL DIVIDER, STREETSIDE INTERMEDIATE - Against sharps close out Install a fixed vertical divider in the streetside intermediate compartment 12" from the wall. Locate to isolate the onboard electrical equipment from the remainder of the storage within the compartment.
1000-0308	1	RIGHT SIDE MOUNTED ELECTRICAL EQUIPMENT Install the onboard electrical components on the right side of the streetside intermediate compartment.
2900-0252	1	EXPANDED METAL CAGE, STREETSIDE INTERMEDIATE Install an expanded metal cage around the onboard electrical equipment per location noted above. Include access ports to equipment with grip lock around the edges of the openings.
2900-1522	1	STREETSIDE REAR COMPARTMENT The height of the streetside rear compartment is to be 3/4 of the available height of the body. See drawings for compartment dimensions. Compartment is to include standard LED strip lighting and a single hinged door.
2000-0404	1	SS REAR COMPT. DIAMONDPLATE The streetside rear compartment is to be fabricated from diamondplate.
2900-0145	1	ADJUSTABLE SHELF STREETSIDE REAR - Centered Install diamond plate adjustable shelving in the streetside rear compartment. Locate as noted.
2900-1526	1	CURBSIDE REAR COMPARTMENT The height of the curbside rear compartment is to be the full available height of the body. See drawings for compartment dimensions. Compartment is to include standard LED strip lighting

		and a single hinged door.
2000-0409	1	CS REAR COMPT. FLAT ALUMINUM The curbside rear compartment is to be fabricated from flat aluminum.
2900-0148	2	ADJUSTABLE SHELF CURBSIDE REAR - Right side of divider for I/O, bottom shelf to be located 40" from floor Install diamond plate adjustable shelving in the curbside rear compartment. Locate as noted.
2900-4070	1	FIXED VERTICAL DIVIDER, CURBSIDE REAR - 11.5" from right wall Install a 16" deep fixed vertical divider in the curbside rear compartment. Locate as noted above.
2000-0611	1	SWEEP OUT COMPARTMENT FLOOR CS REAR COMPT Curbside rear compartment floor is to be sweep-out style.
2900-4001	1	STAIR CHAIR POCKET, CURBSIDE REAR A stair chair pocket is to be recessed into the curbside rear compartment inner door panel. The pocket shall be installed as close to the bottom and hinged side of door as possible. See drawings for dimensions.
2900-2956	1	STAIR CHAIR MODEL, STRYKER #6252 A Stryker #6252 stair chair will be stored as noted. This is for sizing/placement purposes only. Horton is not to supply this equipment.
2900-1530	1	CURBSIDE FORWARD COMPARTMENT The height of the curbside front compartment door is to be the full available height of the body. See drawings for door dimensions. Compartment is to include standard LED strip lighting and a single hinged door.
2900-0110	1	RUBBER MATTING IN EXTERIOR COMPARTMENTS Ribbed black rubber matting will be installed on the floor and shelves of all exterior compartments.
2900-0113	1	RUBBER WALLS IN BB COMPT, GRAY The interior of the backboard compartment is to be covered with gray rubber matting to protect equipment stored in this area.
PAINT AND GRAPHICS		
5000-0003	1	CHASSIS PAINT: WHITE Chassis color to be standard white.
5000-0007	1	MODULE PAINT, WHITE Paint module standard white to match chassis.
5000-0190	3	ACCESS DOORS RED SCOTCHLITE STRIP Install 2" x 12" strips of red Scotchlite at the top of each entry door placed horizontally.
INTERIOR FEATURES		

2000-0288	1	ACRYLIC COLOR: LIGHT TINT All acrylic doors to be light tint.
2000-0293	2	STAINLESS STEEL COUNTER TOPS - Fore and aft of CPR seat Fab and install Stainless pan formed countertops in the patient area.
2000-0592	1	PAINTED STANDARD INHALATION AREA WALLS The main wall action area walls are to be painted to match the remainder of the interior cabinets.
2000-0303	1	INHALATION PANEL, LAMINATE COVERED The inhalation panel is to be fabricated from composite material and covered with laminate to match to color selected.
2000-0457	1	LONCOIN FLECKSTONE BLACK ONYX #150TS The patient area floor is to be covered in Loncoin Fleckstone Black Onyx #150TS.
2000-2101	1	WILSONART FASHION GRAY #D381, RISERS The interior risers are to be made of reinforced structural composite board covered with Wilsonart Fashion Gray #D381 laminate.
2000-0333	1	LAMINATE COVERED LOWER DOOR PANELS Finish lower section of interior patient compartment door panel with laminate as described in the Interior Color section.
2000-2100	1	WILSONART BLACK #1595, ACCENT The interior risers/door panels are to include an accent stripe. Color is to be Wilsonart Black #1595 laminate. Excludes 3-piece stainless steel panels.
SR00097596	1	There will not be a accent stripe on the rear doors.
2000-0441	1	WILSONART FASHION GRAY #D381, WALLS The interior walls are to be made of reinforced structural composite board covered with Wilsonart Fashion Gray #D381 laminate. This does not apply to areas surrounding the inhalation/CPR seat area.
2000-0667	1	FASHION GREY CABINET COLOR All interior cabinetry is to be painted Fashion Grey.
2000-0709	1	CABINET PAINT TO BE SMOOTH The specified cabinet paint is to have a smooth finish.
2000-0670	1	FLINT GREY VINYL COLOR All seat cushions, backrests and vinyl closeouts are to be covered in Flint Grey colored material.
2000-0331	1	USSC CHILD, BLACK 4-POINT, FLINT GREY Install a Flint Gray USSC high back bucket seat with integral child safety seat and black 4pt seatbelt with safety vest. The seat to be adjustable front to rear and is to be mounted at the head of the cot.
2000-0681	1	4 POINT SEAT BELT FOOT OF BENCH, BLACK Install black 4-pt seatbelt with safety vest at the foot position of the squad bench.

2000-0682	1	4 POINT SEAT BELT HEAD OF BENCH, BLACK Install black 4-pt seatbelt with safety vest at the head position of the squad bench.
2000-0683	1	4 POINT SEAT BELT, CPR SEAT, BLACK Install black 4-pt seatbelt with safety vest at CPR seat location.
2000-0605	1	ALUMINUM INTERIOR CABINETS All interior cabinets are to be fabricated from aluminum.
3000-1119	1	TUBULAR AIRBAG, ATTENDANT'S SEAT Install a tubular airbag at the attendant's seat. Unit uses an angled upper inhalation cabinet and includes a cabinet beneath the main countertop.
3000-1125	1	HEAD CURTAIN AIRBAG, ATTENDANT'S SEAT Install a head curtain air bag for the attendant's seat for use with a standard linen cabinet.
3000-1123	1	ROLL SENSOR Install the roll sensor in the standard location. Unit includes streetside airbags only.
3000-1127	1	TUBULAR AIRBAG, CPR SEAT LOCATION. Install a tubular airbag forward of the CPR seat.
2000-0575	1	CABINET TRIM RADIUSED Install smooth radiused trim molding on all applicable interior cabinets.
2900-0079	1	IV HANGER, CP WITH RUBBER ARM COT HEAD - Per Drawing Install a Cast Products recessed IV hanger with rubber arm over the cot head area.
2900-0207	1	IV HANGER, CP WITH RUBBER ARM BENCH CHEST - Per Drawing Install a Cast Products recessed IV hanger with rubber arm over the bench chest area.
2000-0414	1	GRAB RAIL: (2) 2FT ANTI MIC. OVER COT - Per Drawing Install (2) standard style 2' main grab rails with anti-microbial coating. Locate offset toward the main wall over the cot position in the patient area ceiling.
2000-0569	1	GRAB RAIL: 6FT WITH ANTI-MIC, OVER BENCH - Per Drawing Install a standard style 6' main grab rail with anti-microbial coating. Locate offset toward the bench wall in the patient area ceiling.
2000-0419	1	PATIENT DOOR GRAB RAILS: ANTI-MICROBIAL Install standard 'V' shaped grab rails with anti-microbial coating. Locate on the interior door panels of all three patient entry doors.
2000-0423	1	CEILING MATERIAL, PLATINUM WHITE COMPOSITE The standard module ceiling material shall be platinum white aluminum composite.
STREETSIDE CABINETRY		

2000-0337	1	LINEN CABINET Install a standard storage cabinet behind the attendant seat.
2900-1076	1	FIXED SHELF, UPPER LINEN CLOSET Fab and install a fixed aluminum shelf in the upper section of the linen cabinet. Shelf is to be painted to match the cabinet color.
2900-1079	1	ADJUSTABLE SHELF MIDDLE 1 LINEN CLOSET Fab and install an adjustable aluminum shelf in the middle section of the linen cabinet. Shelf is to be painted to match the cabinet color.
2900-1083	1	ADJUSTABLE SHELF LOWER LINEN CLOSET Fab and install an adjustable aluminum shelf in the lower section of the linen cabinet. Shelf is to be painted to match the cabinet color.
2900-2029	2	SOLID LAMINATE-COVERED LINEN CLOSET DOOR Install hinged solid doors on the linen cabinet. Cover in laminate to match the interior.
2900-1070	1	PIANO HINGE FOR LINEN CLOSET TOP DOOR The upper linen cabinet door(s) is/are to use piano style hinge.
2900-1074	1	PIANO HINGE FOR LINEN CLOSET LOWER DOOR The lower linen cabinet door(s) is/are to use piano style hinge.
2900-1183	1	LOCKING SOUTHCO LATCH, UPPER LINEN, CHANGE 10 Install a locking stainless flush mount Southco HD style pull latch on the upper linen cabinet door. Latch to be Change Notice 10 compliant and rated for 25lbs.
2900-1186	1	SOUTHCO LATCH, LOWER LINEN, CHANGE 10 Install a stainless flush mount Southco pull latch on the lower linen cabinet door. Latch to be Change Notice 10 compliant and rated for 25lbs.
2000-0343	1	STREETSIDE WALL WITH CPR SEAT Street side cabinet wall to include a CPR seat.
2000-0310	1	CPR SEAT, 28" WIDTH Streetside CPR seat width to be 28".
SR00097591	1	Install CPR storage compartment for possible future danhard install, ETC. Do not install CPR lift-up seat cushion - No access required.
2900-4089	1	ANGLED UPPER CABINET, FORWARD OF CPR SEAT The upper cabinet forward of the CPR seat is to be angled with .25" aluminum door and steel catch. The cabinet is to be Change Notice 10 compliant.
2900-4088	1	ANGLED UPPER CABINET, AFT OF CPR SEAT The upper cabinet to the rear of the CPR seat is to be angled with .25" aluminum door and steel catch. The cabinet is to be Change Notice 10 compliant.

2000-2050	1	CUSTOM CABINET, Cabinet 1 - Dimensions: 12.75H x 18.75W x 16.0D - Location: BELOW REAR COUNTER Main wall cabinet #1 dimensions are to be as noted above. Note that dimensions are I.D.
2000-1360	1	POLYCARBONATE SLIDING, CHANGE 10, CABINET 1 Cabinet specified above is to have sliding polycarbonate doors. Doors to include CN-10 compliant catch and angled corner brackets.
2000-2051	1	CUSTOM CABINET, Cabinet 2 - Dimensions: 18.75H x 30.5W x 16.0D - Location: Upper Rear Main Wall Main wall cabinet #2 dimensions are to be as noted above. Note that dimensions are I.D.
2000-1361	1	POLYCARBONATE SLIDING, CHANGE 10, CABINET 2 Cabinet specified above is to have sliding polycarbonate doors. Doors to include CN-10 compliant catch.
2900-0172	1	INTERIOR ADJUSTABLE SHELVING, Cabinet 2 Install painted adjustable shelving in cabinet #2.
2000-2058	1	UPPER INHALATION CABINET - 12.75H x 40.75W x 16.0D Upper inhalation cabinet dimensions are to be as noted above. Note that dimensions are I.D.
2000-1368	1	POLYCARBONATE SLIDING, UPPER INHALATION, CHANGE 10 Cabinet over inhalation area is to have sliding polycarbonate doors. Doors to include CN-10 compliant catch.
2900-0347	1	STANDARD S/W DISPOSAL, RECESSED IN ACTION AREA Install sharps and waste disposal in a metal container recessed into the inhalation counter top. Access to the waste receptacle shall be through a spring loaded door. The neck of the sharps container shall protrude through the top surface of the receptacle. Disposal of both containers shall be accessible by raising a hinged aluminum lid.
CURBSIDE CABINETRY		
2000-0359	1	SQUAD BENCH WITH NO CUPS OR WELLS Provide storage under the squad bench lid/cushion(s). The area shall run where possible under the bench. The storage pan is to be fabricated from aluminum and painted to match the interior.
2000-0367	1	SQUAD BENCH END RESTRAINT, BOLSTER Install a standard HOPS bolster at the head end of the bench.
2000-0744	1	DOUBLE CUSHION SQUAD BENCH The squad bench cushion is to be two piece.
2000-0380	1	BENCH HOLD OPENS: GAS Install gas spring hold opens on squad bench lid.
2000-0381	1	BENCH HOLD-DOWN: PADDLE LATCHES (PAIR) Install recessed paddle latches into the squad bench riser to retain the squad bench lids in the closed position. The latches shall be both passive and positive.

2000-0382	1	BENCH CUSHION EDGE TRIM: Trim bench cushion edge with protective aluminum trim, to protect horizontal edge of squad bench cushion from tears.
2000-0383	1	BENCH BACK CUSHION: FULL SIZE Install full size bench backrest cushion.
2000-0516	1	S/W ON A TIP OUT DOOR, FORWARD BENCH Install a tip-out under the head of the squad bench facing the aisle. This door will house both sharps and waste containers. Containers are to be supplied by Horton. Paint cabinet to match interior.
2900-0052	2	BENCH CABINET, HINGED DOORS & O2 OUTLET Fabricate and install a bench ceiling cabinet above the squad bench with lift up Plexiglas doors. The forward portion is to include space for one O2 outlet.
2900-1130	2	SOUTHCO LATCH OVERHEAD BENCH CABINET Install stainless flush mount Southco pull latches on the bench ceiling cabinet.
2900-1137	6	COMPRESSION HINGES, OVERHEAD BENCH CABINET The bench ceiling cabinet door(s) is/are to use compression style hinges.
2900-0136	1	PASS-THROUGH ACCESS, CURBSIDE REAR Provide I/O access into the curbside rear compartment per drawings.
2900-1733	1	CS REAR I/O ACCESS DOOR, HINGED ACRYLIC The compartment pass-through specified above is to have a ½" acrylic vertically hinged door.
2900-0404	1	CS REAR I/O DOOR HINGE, SELF CLOSING STYLE The curbside rear I/O door is to use self-closing style hinges.
2900-0405	1	CS REAR I/O DOOR LATCH, SOUTHCO SS
FRONT WALL CABINETRY		
2900-0073	1	FRONT WALL CABINET: FLAT ALUM PAINTED The front wall cabinet shall be arranged per drawing. Additional configuration information may follow. Cabinet interior is to be painted to match the interior cabinet color.
SR00097593	1	Invert bottom shelf so there is no lip
2900-1737	1	ACRYLIC HINGED DOORS, Upper front wall Cabinet specified above is to have two 1/2" acrylic vertically hinged doors.
2900-1022	4	SOUTHCO FLUSH SS PULL LATCH TOP FRONT WALL DOOR Install stainless flush mount Southco pull latches on the selected hinged doors on the upper front wall cabinet.
2900-1017	6	SELF CLOSING HINGES TOP FRONT WALL CABINET The upper front wall cabinet door(s) is/are to use self-closing style hinges.

2900-1038	1	ADJUSTABLE SHELF, UPPER FRONT WALL TOP CABINET Fab and install an adjustable aluminum shelf in the upper section of the front wall cabinet as noted. Shelf is to be painted to match the cabinet color.
2900-1039	1	FIXED SHELF FRONT WALL MIDDLE CABINET Fab and install a fixed aluminum shelf in the center section of the front wall cabinet as noted. Shelf is to be painted to match the cabinet color.
2900-1042	1	ADJUSTABLE SHELF, LOWER FRONT WALL CABINET Fab and install an adjustable aluminum shelf in the lower section of the front wall cabinet as noted. Shelf is to be painted to match the cabinet color.
2900-1745	1	ACRYLIC HINGED DOORS, Lower front wall Cabinet specified above is to have two 1/2" acrylic vertically hinged doors.
2900-1032	4	SOUTHCO SS PULL STYLE LATCH LOWER FRONT WALL DOOR Install stainless flush mount Southco pull latches on the selected hinged doors on the lower front wall cabinet.
2900-1021	6	SELF CLOSING HINGES LOWER FRONT WALL CABINET The lower front wall cabinet door(s) is/are to use self-closing style hinges.
SR00097590	1	Install a 2 glove box storage above the side entry door.
2000-1404	1	CAB TO MODULE PASSTHROUGH WINDOW Provide a sliding pass-through window between the patient area and the chassis cab on the cab side.
VISUAL WARNING		
3200-5015	2	M7 R/W SPLIT/CLEAR LENS - Wheel wells with red forward Install Whelen M7 series LED lights as noted. Lights to be red/white split with clear lenses. Lights to include chrome flanges and flash pattern programmability from the front control panel.
3000-5085	1	M9 White Clear Lens Front Center KKK Install a Whelen M9 series LED light centered on the front face of the body. Light is to be white with a clear lens. Light is to include a chrome flange and flash pattern programmability from the front control panel.
3000-5104	1	M7 Amber/Clear Lens Rear Center KKK Install a Whelen M7 series LED light centered on the rear face of the body above the rear doors. Light is to be amber with a clear lens. Light is to include a chrome flange and flash pattern programmability from the front control panel.
3000-5018	10	M9 RED/CLEAR LENS - Front body face, upper corners, 2 on street side, 2 curbside, 2 rear face outboard, 2 rear face window level

		Install Whelen M9 series LED lights as noted. Lights to be red with clear lenses. Lights to include chrome flanges and flash pattern programmability from the front control panel.
3300-5021	4	M9 R/W SPLIT/CLEAR LENS - Front face with two on each side of center KKK light Install Whelen M9 series LED lights as noted. Lights to be red/white split with clear lenses. Lights to include chrome flanges and flash pattern programmability from the front control panel.
SR00097595	1	Flash pattern for all warning lights will be alternating rapid double flash pattern
3000-1272	1	RED/CLEAR LENS 500 LED GRILLE, TOP Install (2) Whelen 500 Series red LEDs with clear lenses in the upper chassis grille. To include bezels where applicable.
3000-1287	1	RED/CLEAR LENS 500 TIR6 LED INT. LIGHTS Install (2) Whelen 500 TIR6 Series red LED lights with clear lenses on the chassis fenders. To include housings and weather proof plugs.
AUDIBLE WARNING		
3000-0172	1	SIREN, WHELEN 295SLSA1 - T1 - Wail T2 - Yelp T3 - Piercer Install a Whelen 295SLSA1 siren in the front console.
3000-1543	1	SPEAKERS, CAST PRODUCTS, F SERIES Install Cast Products siren speakers, applicable to Ford F-Series chassis, in the front bumper.
NON-EMERGENCY LIGHTING		
3000-0208	1	KKK SIDE BODY MARKER LIGHTS, M6 SERIES LED (PAIR) Install red Whelen M6 series LED turn/marker lights on each rear side of the module body. Lights provide module body night time side lighting visibility and turning signal indication. Lights do not flash with warning lights unless otherwise specified. Includes chrome flanges.
3000-0217	1	LED EXTERIOR COMPARTMENT LIGHTING Install full height LED strip lighting in all exterior compartments with the exception of any wheelwell compartments. Install vertical strips inside both sides of each compartment. The lights are to be directed toward the back of each compartment.
3000-0221	1	ROLLED ICC MARKER LIGHTS Install standard rolled marker lights along the upper corner post front and rear. Do not install in cases where there are already ICC marker lights installed on a specified lightbar.
3000-0224	1	RUNNING BOARD LIGHTS, WHELEN PAR 16 L.E.D. Install a pair of Whelen PAR 16 LED lamps with chrome flanges in the stainless steel stone guard above each running board, one per side. Wire to the chassis door switch and illuminate the step/running board.

3000-0240	1	M9 SERIES LED SCENE LIGHT, STREETSIDE FRONT Install a Whelen M9 LED side scene light with chrome flange on the upper streetside forward portion of the body.
3000-0741	1	M9 SERIES LED SCENE LIGHT, STREETSIDE REAR Install a Whelen M9 LED side scene light with chrome flange on the upper streetside rear portion of the body.
3000-0748	1	M9 SERIES LED SCENE LIGHT, CURBSIDE FRONT Install a Whelen M9 LED side scene light with chrome flange on the upper curbside forward portion of the body.
3000-0762	1	M9 SERIES LED SCENE LIGHT, CURBSIDE REAR Install a Whelen M9 L.E.D. side scene light with chrome flange on the upper curbside rear portion of the body.
3000-1633	1	LOAD LIGHTS, M9 SERIES LED Install two Whelen M9 LED load lights with chrome flanges above the rear body entry doors.
3000-0261	1	TAIL LIGHTS, M6 SERIES, VERTICAL MOUNT Install Whelen M6 series LED stop/tail, reverse, and turn signals. Install lights stacked vertically above the rear riser in the rear body panels to either side of the rear access doors. All lights to include chrome flanges.
ELECTRICAL		
3000-0018	1	ELECTRIC DOOR LOCKS COMPARTMENT EXTERIOR Install power activated door locks on all exterior compartment doors. Locks to be activated by a switch at each patient area access door. Locks may be overridden by a door key.
3000-0019	1	ELECTRIC DOOR LOCKS ACCESS DOORS INTERIOR Install power activated door locks on all patient area access doors. Locks to be activated by a switch at each patient area door. Locks may be overridden by a manual slide lever or by the door key.
3000-0022	1	ELECTRIC DOOR LOCKS WIRED TO OEM SWITCHES The specified power door locks are to be wired to the chassis OEM door lock switches.
3000-0020	1	ELECTRIC DOOR LOCKS CONCEALED IN GRILLE Install a concealed switch in the chassis grille to operate the power door lock circuit. Doors shall be wired to unlock only on this circuit.
3000-0282	1	ELECTRICAL SYSTEM Install the Intelliplex i4G electrical system. System is to include a USB port installed under the dash for ease of programming.
3000-0305	1	INPOWER BATTERY SWITCH, WITH WAKE BUTTON - 5 min. Install an Inpower electronic battery switch. Switch is to activate battery power through the vehicle ignition and is to include an automatic shutdown timer to deactivate battery power after the ignition is

		turned off. To include a wake button installed on the front console to activate the electrical system without using the key.
3000-0535	1	1050CUL W/CHARGER, MULTIPLEX Install a Vanner #20-1050CUL combination inverter/charger in the streetside intermediate compartment. Included will be a Vanner Interface Module, Inverter Status Panel, and Charger Status Panel. A switch will be installed in the rear control panel for operation. Locate Charger status panel near the shoreline inlet and the inverter status panel within view of the operator.
3000-0310	2	110V INTERIOR OUTLET - 1 In Inhalation Area And 1 Front wall cabinet Install a 110V outlet(s) as noted.
3000-0549	3	INTERIOR 12VDC OUTLETS: CL TYPE/USB - 1 In Inhalation Area, 1 In Upper Front Wall Cabinet and 1 in the passenger side of console - upper vertical side Install a 12VDC cigarette style/USB outlet(s) as noted. Wire battery hot.
3000-1463	1	SHORELINE 1, 20A SUPER AUTO EJECT, WHITE Mount a Kussmaul Super Auto Eject 20 amp shoreline inlet in the standard location. Cover is to be white.
3000-1500	1	PD BOX LOCATION, LEFT HAND SIDE, SS INT. COMPARTMENT Install the power distribution panel on the left hand side of the streetside intermediate compartment. Close off this area from the remainder of the compartment.
3000-0324	1	SHORELINE INDICATOR 1: Install an indicator pilot light to show power to A.C. circuits and presence of activated primary shoreline.
3000-0327	1	EXTRA 12VDC CIRCUIT BREAKER: INTERMEDIATE COMPT An extra circuit breaker shall be installed in the streetside intermediate compartment.
3000-0332	1	REPORT LIGHT, LED Install a 12" LED report light on the action wall to light the counter area.
3000-0344	1	STEP WELL LIGHT VISTA LED Install a 10.5" LED Vista light strip in the standard location on the bench side of the step well. Light to activate with door open.
3000-0346	1	2.5" CAB CEILING LIGHTS, WHITE/RED LED Install (2) combination white/red LED dome lights in the cab headliner. Locate one light over the driver and one light over the passenger. Wire to a switch in the front control panel and provide 'OFF'. 'CLEAR' and 'RED' selections.
3000-0359	7	PATIENT CEILING DOME LIGHTS WHELEN LED Install Whelen 80COEHCR LED dome lights in the patient area ceiling. The lights will have a high/low feature with the switch in the rear control panel.
3000-0525	1	3 SWITCH PANEL REAR DOOR PANEL Install an i4G 3-switch control panel on the right rear entry door panel.

3000-5042	1	DUMP OVERRIDE, i4G, REAR DOOR PANEL Install the dump override switch in the panel selected for the right rear entry door inner panel.
3000-0526	1	3 SWITCH PANEL SIDE ACCESS DOOR Install an i4G 3-switch control panel on the side entry door panel.
3000-2104	1	TIMER, DOME LIGHTS, SIDE ACCESS DOOR Install an electronic momentary touch timer switch in the specified I4g switch panel on the side access door panel. The switch will enable time limited operation of the specified dome lights with the battery switch in the 'off' position. Set timer to 15 minutes.
3000-0007	1	BACKUP ALARM RESET, MOMENTARY Install a back-up alarm and provide a momentary backup alarm reset button on the front console.
3000-0031	1	CAMERA LOCATION: OVER REAR DOORS, EXTERIOR The integrated camera system noted is to include a camera installed over the rear doors on the vehicle exterior for use in reverse.
SR00097600	1	Install prewire for a power load cot.
PROGRAMMING		
6000-0001	1	LIGHT PROGRAMMING: SIDE REAR SCENE The side rear scene lights shall be wired to transmission reverse, plus standard mode of operation.
6000-0002	1	LIGHT PROGRAMMING: RIGHT SIDE SCENE The right side scene lights shall come "on" when the side patient door is opened.
6000-0003	1	LIGHT PROGRAMMING: LOAD LIGHT Program the rear load lights to activate with transmission reverse plus the standard mode of operation.
6000-0018	1	WHITE LIGHT CUTOFF SWITCH Provide a switch in the front control panel to deactivate all forward facing white lights. This includes wig wag flashers if ordered.
6000-0006	1	PROGRAMMING: AUDIBLE LOW VOLTAGE ALARM Program an audible alarm to activate if the voltage drops below 11.8 volts for 120 seconds.
6000-0007	1	LIGHT PROGRAMMING: PARK BRAKE Program a warning to display on the front console readout advising to set the Parking Brake when the module disconnect switch is "ON" and the transmission is placed in "PARK" or "NEUTRAL". It will also advise to Disengage the Parking Brake should the vehicle be placed into gear.
HVAC		
3000-1616	1	COOLTECH I, F SERIES Install a Cool-Tech I 4-fan 100,000 BTU condenser in the recessed pocket in the roof of the body.
3000-4027	1	12V HVAC, ATTENDANT'S SEAT

		Install a ProAir Pre-charged 12V heat/AC system with brushless motor below the attendant seat.
3000-0427	1	NFPA COMPLIANT VENTING, CAST Install an NFPA style venting system to include a 400cfm exhaust fan along with a static vent. Install 9.5" square polished covers on both vents per drawings.
RADIO		
3000-0432	1	ANTENNA COAX 1 - Start: Cab Console, End: Front Center of Mod Roof An RG 58U coax shall be installed terminating as noted above.
3000-0608	1	ANTENNA COAX 2 - Start: Inhalation Wall, End: Center of Mod Roof An RG 58U coax shall be installed terminating as noted above.
1000-0411	1	CONSOLE, LINE-X, W/MAP STORAGE, F SERIES Fabricate and install an aluminum cab console and spray with black Line-X material. Console is to include three (3) map/book slots at the rear of the console.
SR00097599	1	Recess the front control panel into the console face plate.
1000-0179	1	CUP HOLDERS, 2-TIER Install two (2) two-tier style cup holders recessed into the console.
3000-5157	1	POWER TERMINAL, DUAL, INSIDE CONSOLE Install three (3) 10 gauge 30 amp cables to positive and ground studs for radio power. Wire one constant hot, one battery switched, and the third as a ground.
3000-5160	1	POWER TERMINAL, DUAL, INHALATION PANEL Install three (3) 10 gauge 30 amp cables to positive and ground studs for radio power. Wire one constant hot, one battery switched, and the third as a ground.
OXYGEN		
4000-0001	1	O2 MOUNT, VERT TRACK FOR QRM-V Vertical track for mounting of a QRM-V O2 bottle mount shall be welded on the back wall of the streetside forward compartment in the right hand corner. Bracket will be set up for an 'M' sized bottle.
4000-0018	1	O2 BOTTLE, BRACKET QRM-V Install a Zico QRM-V oxygen bracket for 'M' bottle. Locate in the streetside forward compartment.
4000-0019	1	OXYGEN ACCESS Provide access to the oxygen cylinder valve through the wall as depicted on the drawings. The door shall be hinged so that it swings into the oxygen cylinder storage compartment. Door

		material is to match other selected cabinet doors. The opening shall be 7" wide x 11" high and trimmed with anodized aluminum.
4000-0022	3	O2 OUTLET, OHIO MEDICAL - 1 in the inhalation panel, 1 forward end of bench and 1 in the ceiling above chest of cot Install O2 outlets per instructions above. Outlets to be Ohio Medical style.
4000-0025	1	OXYGEN WRENCH Install oxygen wrench in oxygen compartment. Mount securely to wall. Mount with length of chain or cable to allow for use without being removed from the compartment.
4000-0179	1	ASPIRATOR, SSCOR, INHALATION AREA Install an SSCOR aspirator. The system shall include a wall mounted regulator and a canister holder. Plumb to the selected pump.
4000-0184	1	VACUUM PUMP CFP #107CDC20 Install a CFP #107CDC20 12vdc electric suction pump.
CERTIFICATIONS		
7000-0001	1	KKK-A-1822F CERTIFICATION LABEL The vehicle shall have weight/payload, electrical load and KKK-A-1822F certification stickers installed in the O2 compartment.
7000-0003	1	CHANGE NOTICE 10 CERTIFICATION The vehicle shall be certified to change notice 10 standards.